

RJ 45 Crimping







| Pin number Wire Color |
|------------------------|
| Pin 1 ==> Orange/White |
| Pin 2 ==> Orange |
| Pin 3 ==> Green/White |
| Pin 4 ==> Blue |
| Pin 5 ==> Blue/White |
| Pin 6 ==> Green |
| Pin 7 ==> Brown/White |
| Pin 8 ==> Brown |



| Wire Color |
|------------|
| ange/White |
| ange |
| een/White |
| ue |
| ue/White |
| reen |
| own/White |
| own |
| |

| Crossed-Over | | | | | |
|--------------|---------------|--------|--|--|--|
| Wire | В | ecomes | | | |
| 1 | \rightarrow | 3 | | | |
| 2 | \rightarrow | 6 | | | |
| 3 | \rightarrow | 1 | | | |
| 6 | \rightarrow | 2 | | | |

| Pin number | Wire Color |
|--------------|------------|
| Pin 1 ==> Gr | een/White |
| Pin 2 ==> Gr | een |
| Pin 3 ==> Or | ange/White |
| Pin 4 ==> Bl | |
| Pin 5 ==> Bl | e/White |
| Pin 6 ==> Or | ange |
| Pin 7 ==> Br | |
| Pin 8 ==> Br | own |

CAT 5-100 Mbps, CAT 5e-upto~350 Mbps, CAT 6-1000 Mbps or 1 Gbps

| S.No | A- End | B-End | Required Cable |
|------|-----------------|--------------|------------------|
| 1 | Switch | PC | Straight Through |
| 2 | Switch | Switch | Straight Through |
| 3 | Switch | Router | Straight Through |
| 4 | Switch | Lan Extender | Straight Through |
| 5 | Lan Extender | PC | Straight Through |
| 6 | Media Convertor | PC | Straight Through |
| 7 | PC | PC | Crossed Over |